

SAMSUNG S PEN SDK

Instructor: Nguyễn Kiêm Hùng

WHAT IS PEN SDK

- S PEN is a new type of input device available on Note range of devices.
- Requirements:
 - Devices with Android 4.0 Ice Cream Sandwich (API level 14) or higher support Pen.
 - Between minimum resolution of 480x800 and maximum resolution of 1600x2580 are supported.
 - Some functions such as writing pressure or hover can be limited if Pen is not used.



WHAT IS PEN SDK

- allows you to develop applications, such as S Note, that use handwritten input
- uses a pen, finger or other kinds of virtual pens for input

Advantages of S Pen

1


Precise and quick response
Supports pen pressure

2

No power consumption
Lightweight hardware


3

Side button, pen hovering
→ A new UX



WHAT IS PEN SDK

- **What's the Benefit?**
 - Recognize the side button with or without contact.




WHAT IS PEN SDK

■ Some use cases


Graphics



Memo & Planner



Game




SNS



Education



B2B




WHAT IS PEN SDK

- Pen supports the following features:
 - Advanced edit
 - Recognition

WHAT IS PEN SDK

■ Advanced edit:

- a drawing engine based on Stroke
- offers advanced edit functions, such as selection, multiple selection, group/ungroup, move forward/backward, and zoom in/out



WHAT IS PEN SDK


- **Advanced edit:**
 - **Pen:** Various tools such as brushes, color pens and more



WHAT IS PEN SDK

- **Recognition:**

- to convert objects written on the canvas to drawings




Draw a triangle and select it so that the system recognizes it as an object consisting of lines

WHAT IS PEN SDK

■ Recognition:


- to convert objects written on the canvas to drawings



Write a formula that is converted the image into a digital format.

WHAT IS PEN SDK

- **Recognition:**
 - to convert objects written on the canvas to drawings



Handwritten Text Search

USING PEN SDK

- **Samsung Device Requirements:**
 - S-Pen support
 - Android 4.0 Ice Cream Sandwich (API level 14)
 - S-Pen SDK package

USING PEN SDK


■ System Requirements

- JDK (Java Development Kit): required for developing and running Java applications.
 - Download and Install Java 8 for Microsoft Windows:
<http://www.oracle.com/technetwork/java/javase/downloads/index.html>
- Android Studio (Including IDE + ADT plug-in, Emulator ...): provides everything you need to start developing apps for Android
 - Download and install Android Studio:
<http://developer.android.com/sdk/index.html>

■ Downloading the PEN SDK with the Android SDK Manager


USING PEN SDK

- Setup JDK Location in Android Studio
 - Select File - Project Structure




RUNNING SAMPLE APPLICATION

- Run **Android Studio** and click **File → (New →) Import Project...** to open the **Import** dialog
 - The sample application for PEN SDK is in the 'Samples' directory of the downloaded SDK package



RUNNING SAMPLE APPLICATION

- S Pen sample application include all features of the PEN SDK package.



PEN PROGRAMMING GUIDE


- **PEN SDK** allows you to develop applications that use handwritten inputs: S pen, finger, etc.
- **PEN SDK** provides functions for verifying if the S pen is activated, identifying event coordinates, sensing the pressure, verifying if the side button is pressed, processing hover events and more for your application.
- **You can use Pen to:**
 - draw using a **finger** and/or **S pen**
 - set **user preferences** for pens, erasers, and text
 - edit and save input objects (text, strokes, and images) as a file
 - manage history for undo and redo commands

PEN PROGRAMING GUIDE

- **The Pen motion events include:**
 - Touch events occur when a S pen touches the screen
 - Hover events occur when a S pen is within a certain range of the screen.


PEN PROGRAMING GUIDE

- **SpenSurfaceView** class processes finger and S pen inputs to express data on the viewport.
- Objects drawn on an **SpenSurfaceView** instance are saved in **SpenPageDoc**, with multiple SpenPageDocs making an **SpenNoteDoc** file.




PEN PROGRAMING GUIDE

■ PEN SDK Architecture



PEN PROGRAMING GUIDE

- Model-View-Control paradigm of S Pen 3.0 Architecture



PEN PROGRAMING GUIDE

- **Components**
 - Pen-v3.1.3.jar
 - Sdk-v1.0.0.jar

PEN PROGRAMING GUIDE

■ Implementation


- **Step 1: Initializing** the instance of the **Spen** class by calling the **initialize()** method requiring a context as parameter.
- **Step 2: Creating an S Pen Surface View**
 - Simply create an object of the **SpenSurfaceView** class then set the object as parameter to the **Relative layout addView()** method.
- **Step 3: Adding the Pen Setting View**
 - To add a Pen Setting View, add the same instance of the **Relative layout** used in creating the **S pen surface view** to the instance of the **SpenSettingPenLayout** through its constructor method requiring it as a parameter.
- **Step 4: Adding the Eraser Setting View**
 - To add a Pen Setting View, add the same instance of the **Relative layout** used in creating the **S pen surface view** to the instance of the **SpenSettingEraserLayout** through its constructor method requiring it as a parameter.

FIRT PROGRAM: Hello Pen

- **Hello Pen is a simple program that:**
 - gets input from a S pen
 - expresses drawing on the viewport

FIRT PROGRAM: Hello Pen

■ Creating a New Project in Android Studio



The screenshot shows the 'Create New Project' dialog in Android Studio. The dialog has a green header with the Android Studio logo and the text 'New Project' and 'Android Studio'. Below the header, the text 'Configure your new project' is displayed. The dialog contains four input fields: 'Application name' with the value 'Hello_Pen', 'Company Domain' with the value 'sislab.example.com', 'Package name' with the value 'com.example.sislab.hello_pen', and 'Project location' with the value 'C:\Users\sislab\AndroidStudioProjects\Hello_Pen'. The 'Next' button is highlighted in blue, and the 'Previous', 'Cancel', and 'Finish' buttons are grayed out.

Create New Project

New Project
Android Studio

Configure your new project

Application name: Hello_Pen

Company Domain: sislab.example.com


Package name: com.example.sislab.hello_pen Edit

Project location: C:\Users\sislab\AndroidStudioProjects\Hello_Pen ...

Previous Next Cancel Finish

FIRT PROGRAM: Hello Pen

■ Creating a New Project in Android Studio



The screenshot shows the 'Create New Project' dialog in Android Studio. The window title is 'Create New Project'. The main heading is 'New Project' with the Android Studio logo. Below this, it says 'Select the form factors your app will run on' and 'Different platforms require separate SDKs'. There are two options: 'Phone and Tablet' (checked) and 'TV' (unchecked). Under 'Phone and Tablet', there is a 'Minimum SDK' dropdown menu set to 'API 14: Android 4.0 (IceCreamSandwich)'. Below the dropdown, there is a note: 'Lower API levels target more devices, but have fewer features available. By targeting API 14 and later, your app will run on approximately 87.9% of the devices that are active on the Google Play Store. [Help me choose.](#)'. At the bottom right, there are four buttons: 'Previous', 'Next' (highlighted in blue), 'Cancel', and 'Finish'.

Create New Project

New Project
Android Studio

Select the form factors your app will run on

Different platforms require separate SDKs

☒ Phone and Tablet

Minimum SDK: API 14: Android 4.0 (IceCreamSandwich)

☐ TV

Lower API levels target more devices, but have fewer features available. By targeting API 14 and later, your app will run on approximately **87.9%** of the devices that are active on the Google Play Store. [Help me choose.](#)

Previous Next Cancel Finish


FIRT PROGRAM: Hello Pen

■ Creating a New Project in Android Studio



FIRT PROGRAM: Hello Pen

■ Creating a New Project in Android Studio



Create New Project

Choose options for your new file

Creates a new blank activity with an action bar.

Activity Name: HelloPen

Layout Name: activity_hello_pen


Title: HelloPen

Menu Resource Name: menu_hello_pen

Previous Next Cancel Finish


FIRT PROGRAM: Hello Pen

- Adding a Library of the downloaded PEN SDK to "libs" folder of the newly created project.
 - Copy the **SDK .jar files** to the 'libs' folder in your new project to use the SDK you need for your application.




FIRT PROGRAM: Hello Pen

- Adding a Library of the downloaded PEN SDK to “libs” folder of the newly created project.
 - Select .jar files and Right click to show a pop-down menu, select “Add as libraries”.




FIRT PROGRAM: Hello Pen

- **Adding a Library** of the downloaded Chord SDK to **"MAIN"** folder of the newly created project.
 - Create a "jnitlibs" folder in **"MAIN"** folder of the newly created project
 - Copy the **"armeabi"** folder in "libs" of the downloaded Spen SDK to the 'jnitlibs' folder.



FIRT PROGRAM: Hello Pen

- Adding a Library of the downloaded PEN SDK to “libs” folder of the newly created project.
 - Check **.jar files** have been added into the project as shown in figure.



FIRT PROGRAM: Hello Pen

- Adding source code.
 - Hello_pen.pdf

FIRT PROGRAM: Hello Pen

- **Add the following permission to your Android manifest file (*app\src\main\AndroidManifest.xml*):**

```
// add permission
<uses-permission
android:name="android.permission.WRITE_EXTERNAL_STORAGE"/>
<uses-permission android:name="android.permission.CAMERA"/>
<uses-permission
android:name="com.samsung.android.providers.context.permission.WRI
TE_USE_APP_FEATURE_SURVEY" />
```

FIRT PROGRAM: Hello Pen

- Open "activity_hello_pen.xml" file:
 - Delete: `<TextView android:text ...>`
 - Add: `android:id="@+id/spenViewLayout">`

```
<RelativeLayout xmlns:android="http://schemas.android.com/apk/res/android"
    xmlns:tools="http://schemas.android.com/tools" android:layout_width="match_parent"
    android:layout_height="match_parent"
    android:paddingLeft="@dimen/activity_horizontal_margin"
    android:paddingRight="@dimen/activity_horizontal_margin"
    android:paddingTop="@dimen/activity_vertical_margin"
    android:paddingBottom="@dimen/activity_vertical_margin" tools:context=".HelloPen"
    android:id="@+id/spenViewLayout">
```

```
</RelativeLayout>
```

FIRT PROGRAM: Hello Pen

- Open "HelloPen.java" file and replace *class Hellopen* with the following codes:

```
public class HelloPen extends ActionBarActivity {

    private Context mContext;
    private SpenNoteDoc mSpenNoteDoc;
    private SpenPageDoc mSpenPageDoc;
    private SpenSurfaceView mSpenSurfaceView;

    @Override
    protected void onCreate(Bundle savedInstanceState) {
        super.onCreate(savedInstanceState);
        setContentView(R.layout.activity_hello_pen);
        mContext = this;

        // Initialize Pen.
        boolean isSpenFeatureEnabled = false;
        Spen spenPackage = new Spen();
        try {
            spenPackage.initialize(this);
            isSpenFeatureEnabled =
            spenPackage.isFeatureEnabled(Spen.DEVICE_PEN);
        } catch (SsdkUnsupportedException e) {
            Toast.makeText(mContext, "This device does not support S pen.",
                Toast.LENGTH_SHORT).show();
            e.printStackTrace();
            finish();
        }
    }
}
```


FIRT PROGRAM: Hello Pen

- Open "HelloPen.java" file and replace *class Hellopen* with the following codes:

```
} catch (Exception e1) {
    Toast.makeText(mContext, "Cannot initialize Pen.",
        Toast.LENGTH_SHORT).show();
    e1.printStackTrace();
    finish();
}

// Create Pen View.
RelativeLayout spenViewLayout =
    (RelativeLayout) findViewById(R.id.spenViewLayout);
mSpenSurfaceView = new SpenSurfaceView(mContext);
if (mSpenSurfaceView == null) {
    Toast.makeText(mContext, "Cannot create new SpenSurfaceView.",
        Toast.LENGTH_SHORT).show();
    finish();
}
spenViewLayout.addView(mSpenSurfaceView);

// Get the dimensions of the screen.
Display display = getWindowManager().getDefaultDisplay();
Rect rect = new Rect();
display.getRectSize(rect);
// Create SpenNoteDoc.
try {
```

FIRT PROGRAM: Hello Pen

- Open "HelloPen.java" file and replace *class Hellopen* with the following codes:

```
mSpenNoteDoc =
    new SpenNoteDoc(mContext, rect.width(), rect.height());
} catch (IOException e) {
    Toast.makeText(mContext, "Cannot create new NoteDoc.",
        Toast.LENGTH_SHORT).show();
    e.printStackTrace();
    finish();
} catch (Exception e) {
    e.printStackTrace();
    finish();
}
// After adding a page to NoteDoc, get an instance and set it
// as a member variable.
mSpenPageDoc = mSpenNoteDoc.appendPage();
mSpenPageDoc.setBackgroundColor(0xFFD6E6F5);
mSpenPageDoc.clearHistory();
// Set PageDoc to View.
mSpenSurfaceView.setPageDoc(mSpenPageDoc, true);

if(isSpenFeatureEnabled == false) {
    mSpenSurfaceView.setToolTypeAction(SpenSurfaceView.TOOL_FINGER,
        SpenSurfaceView.ACTION_STROKE);
    Toast.makeText(mContext,
        "Device does not support S pen. \n You can draw strokes with your finger",
```

FIRT PROGRAM: Hello Pen

- Open "HelloPen.java" file and replace *class Hellopen* with the following codes:

```
        Toast.LENGTH_SHORT).show();
    }
}

@Override
protected void onDestroy() {
    super.onDestroy();

    if(mSpенSurfaceView != null) {
        mSpенSurfaceView.close();
        mSpенSurfaceView = null;
    }

    if(mSpенNoteDoc != null) {
        try {
            mSpенNoteDoc.close();
        } catch (Exception e) {
            e.printStackTrace();
        }
        mSpенNoteDoc = null;
    }
};
}
```

FIRT PROGRAM: Hello Pen

■ Import classes to “HelloPen.java” file:

```
import android.content.Context;  
import android.widget.Toast;
```

```
import com.samsung.android.sdk.SsdkUnsupportedException;  
import com.samsung.android.sdk.pen.Spen;  
import com.samsung.android.sdk.pen.document.SpenNoteDoc;  
import com.samsung.android.sdk.pen.document.SpenPageDoc;  
import com.samsung.android.sdk.pen.engine.SpenSurfaceView;
```

Using the S-Pen Class

■ The Spen class provides the following methods:

- **initialize()** initializes Pen.

- You need to initialize Pen before you can use it:

- void initialize (Context context) throws SsdkUnsupportedException*

- If the device does not support S Pen, SsdkUnsupportedException is thrown.

- **getVersionCode()** returns the Pen SDK version number as an integer.

- **getVersionName()** returns the Pen SDK version name as a string.

- **isFeatureEnabled()** checks if a Pen feature is available on the device.

Using the S-Pen Class

- If an **SsdkUnsupportedException** exception is thrown, check the exception message type using **SsdkUnsupportedException.getType()**:
 - **VENDOR_NOT_SUPPORTED**: The device is not a Samsung device.
 - **DEVICE_NOT_SUPPORTED**: The device does not support Pen.
 - **LIBRARY_NOT_INSTALLED**: SpenSdk3.apk is not installed on the device.
 - **LIBRARY_UPDATE_IS_REQUIRED**: A necessary update for the Pen library or SpenSdk3.apk. If the library or apk is not updated, the user cannot use the application.
 - **LIBRARY_UPDATE_IS_RECOMMENDED**: A recommendation to update the Pen library or SpenSdk3.apk, but it is not mandatory. The user can use the application without updating them.

Using the S-Pen Class

■ Checking the Availability of Pen Features:

- Using isFeatureEnabled() method:

`boolean isFeatureEnabled(int type)`

- If the method returns false (which means S pen are not supported), **you can enable users to use their fingers:**

```
if(spenPackage.isFeatureEnabled(Spen.DEVICE_PEN) == false) {  
    mSpenSurfaceView.setToolTypeAction(SpenSurfaceView.TOOL_FINGER,  
        SpenSurfaceView.ACTION_STROKE);  
    Toast.makeText(mContext,  
        "Device does not support S pen. \n You can draw strokes with your finger",  
        Toast.LENGTH_SHORT).show();  
}
```

QUIZ

- **Modify your code so that you can use your finger to input information into Samsung devices**

Using Pen Views

■ *"SpenSurfaceView" class:*

- processes finger gestures or S pen input to express drawings on the viewport.
- converts handwritten input to text or replays user input.
- provides controls for scaling, rotating, moving, and selecting objects.
- Combines with "SpenSettingPenLayout" to provide methods for managing user preferences (e.g. font, font size, and font color; the size, color, or type of the pen tool; the size of the eraser tool; and options for objects).

Using Pen Views

- **To create a drawing container in your application:**
 - Create an **SpenSurfaceView** instance by passing your application **Context** to the **SpenSurfaceView** constructor.
 - Add the **SpenSurfaceView** instance to the main layout.

```
RelativeLayout spenViewLayout = (RelativeLayout)
findViewById(R.id.spenViewLayout);
mSpenSurfaceView = new SpenSurfaceView(mContext);
if (mSpenSurfaceView == null) {
    finish();
}
spenViewLayout.addView(mSpenSurfaceView);
```

Using Pen Views

- **Creating a container to save input data from the `SpенSurfaceView` instance:**
 - Create an `SpенNoteDoc` instance by passing your application Context and the width and height of the `SpенSurfaceView` instance to the `SpенNoteDoc` constructor.
 - Call `SpенPageDoc.setBackgroundColor()` to specify the background color.
 - Use the `SpенSurfaceView.setPageDoc()` method to connect the `SpенPageDoc` instance to your `SpенSurfaceView` instance.

Using Pen Views

- **Creating a container to save input data from the *SpenSurfaceView* instance:**

```
try {  
    mSpenNoteDoc = new SpenNoteDoc(mContext, rect.width(), rect.height());  
} catch (IOException e) {  
    e.printStackTrace();  
    finish();  
} catch (Exception e) {  
    e.printStackTrace();  
    finish();  
}  
  
// After adding a page to NoteDoc, get an instance  
// and set it as a member variable.  
mSpenPageDoc = mSpenNoteDoc.appendPage();  
mSpenPageDoc.setBackgroundColor(0xFFD6E6F5);  
mSpenPageDoc.clearHistory();  
// Set PageDoc to View.  
mSpenSurfaceView.setPageDoc(mSpenPageDoc, true);
```

Using Pen Views

■ Preventing Memory Leaks:

- Call **SpenNoteDoc.close()** and **SpenSurfaceView.close()** to close the **SpenNoteDoc** and **SpenSurfaceView** instances to prevent memory leaks when your application closes.

```
protected void onDestroy() {  
    super.onDestroy();  
  
    if (mSpenSurfaceView != null) {  
        mSpenSurfaceView.close();  
        mSpenSurfaceView = null;  
    }  
  
    if (mSpenNoteDoc != null) {  
        try {  
            mSpenNoteDoc.close();  
        } catch (Exception e) {  
            e.printStackTrace();  
        }  
        mSpenNoteDoc = null;  
    }  
}
```

Using Pen Views

■ Preventing Memory Leaks:

- Call **SpennoteDoc.close()** and **SpennoteSurfaceView.close()** to close the **SpennoteDoc** and **SpennoteSurfaceView** instances to prevent memory leaks when your application closes.

```
protected void onDestroy() {  
    super.onDestroy();  
  
    if (mSpennoteSurfaceView != null) {  
        mSpennoteSurfaceView.close();  
        mSpennoteSurfaceView = null;  
    }  
  
    if (mSpennoteDoc != null) {  
        try {  
            mSpennoteDoc.close();  
        } catch (Exception e) {  
            e.printStackTrace();  
        }  
        mSpennoteDoc = null;  
    }  
}
```


Using Pen Setting

■ Objective:

- add a pen settings button to your application for setting user preferences for the pen size, color and type.

■ Description:

- When the button is clicked, the SpenSettingPenLayout view appears to allow the user to configure the settings for the pen. If the button is clicked again, the window closes.



Using Pen Setting

- **Creating a New Project in Android Studio**
 - Application Name: **Demo_Pen**
 - Activity Name: **DemoPen**
- **Modify "AndroidManifest.xml"**
- **Add libraries**
- **Add source code:**
 - **Demo_pen.pdf**

Using Pen Setting

■ Edit Code of "Activity_demo_pen.xml":

```
<LinearLayout xmlns:android="http://schemas.android.com/apk/res/android"
    xmlns:tools="http://schemas.android.com/tools"
    android:layout_width="match_parent"
    android:layout_height="match_parent"
    android:orientation="vertical"
    tools:context=".DemoPen" >
```

```
<LinearLayout
    android:id="@+id/tool_menu"
    android:layout_width="match_parent"
    android:layout_height="wrap_content" >
```

```
<Button
    android:id="@+id/penBtn"
    android:layout_width="match_parent"
    android:layout_height="wrap_content"
    android:text="Pen Setting"/>
```

```
</LinearLayout>
```

```
<FrameLayout
    android:id="@+id/spenViewContainer"
    android:layout_width="match_parent"
    android:layout_height="match_parent" >
```

```
<RelativeLayout
    android:id="@+id/spenViewLayout"
    android:layout_width="match_parent"
    android:layout_height="match_parent" >
```

```
</RelativeLayout>
```

```
</FrameLayout>
```

```
</LinearLayout>
```

Using Pen Setting

- Creating **SpenSurfaceView** and **penSettingPenLayout**
 - Call `addView()` and add your `SpenSettingPenLayout` instance to the `SpenSurfaceView` container defined in `FrameLayout`.
 - To connect the settings view to your `SpenSurfaceView` instance, call `SpenSettingPenLayout.setCanvasView()` and pass your `SpenSurfaceView` instance.

Using Pen Setting

■ Creating `SpenSurfaceView` and `penSettingPenLayout`

```
FrameLayout spenViewContainer =
    (FrameLayout) findViewById(R.id.spenViewContainer);
RelativeLayout spenViewLayout =
    (RelativeLayout) findViewById(R.id.spenViewLayout);

// Create PenSettingView.
mPenSettingView =
    new SpenSettingPenLayout(mContext, new String(),
        spenViewLayout);
if (mPenSettingView == null) {
    Toast.makeText(mContext, "Cannot create new PenSettingView.",
        Toast.LENGTH_SHORT).show();
    finish();
}
spenViewContainer.addView(mPenSettingView);

// Create Pen View.
mSpenSurfaceView = new SpenSurfaceView(mContext);
if (mSpenSurfaceView == null) {
    Toast.makeText(mContext, "Cannot create new SpenSurfaceView.",
        Toast.LENGTH_SHORT).show();
    finish();
}
spenViewLayout.addView(mSpenSurfaceView);
mPenSettingView.setCanvasView(mSpenSurfaceView);
```

Using Pen Setting

■ Initializing Pen Settings

- Create an `SpenSettingPenInfo` instance with your default settings for the pen tool.
- Call `SpenSurfaceView.setPenSettingInfo()` to save the settings modified on your `SpenSurfaceView` instance.
- Call `setInfo()` to save the settings to your `SpenSettingPenLayout` instance.

Using Pen Setting

■ Initializing Pen Settings

```
private void initPenSettingInfo() {  
    // Initialize pen settings.  
    SpenSettingPenInfo penInfo = new SpenSettingPenInfo();  
    penInfo.color = Color.BLUE;  
    penInfo.size = 10;  
    mSpnSurfaceView.setPenSettingInfo(penInfo);  
    mPenSettingView.setInfo(penInfo);  
}
```

Using Pen Setting

- **Registering a Listener for the Pen Settings Button**
 - Create a pen Settings button.

```
mPenBtn = (Button) findViewById(R.id.penBtn);  
mPenBtn.setOnClickListener(mPenBtnClickListener);
```


Using Pen Setting

- **Registering a Listener for the Pen Settings Button**
 - calling `setOnClickListener()` to handle the button click events.

```
private final View.OnClickListener mPenBtnClickListener = new View.OnClickListener() {
    @Override
    public void onClick(View v) {
        // If PenSettingView is open, close it.
        if (mPenSettingView.isShown()) {
            mPenSettingView.setVisibility(View.GONE);
            // If PenSettingView is not open, open it.
        } else {
            mPenSettingView.setViewMode(SpenSettingPenLayout.VIEW_MODE_EXTENSION);
            mPenSettingView.setVisibility(View.VISIBLE);
        }
    }
};
```

Using Pen Setting

- **Registering a Listener for Color Picking**
 - Create an `SpenColorPickerListener` listener instance for the color picker in the `SpenSettingPenLayout` view and handle the event it returns.



Using Pen Setting

■ Registering a Listener for Color Picking

- Create an `SpenColorPickerListener` listener instance for the color picker in the `SpenSettingPenLayout` view and handle the event it returns.

```
private final SpenColorPickerListener mColorPickerListener = new
SpenColorPickerListener() {
    @Override
    public void onChanged(int color, int x, int y) {
        // Set the color from the Color Picker to the setting view.
        if (mPenSettingView != null) {
            SpenSettingPenInfo penInfo = mPenSettingView.getInfo();
            penInfo.color = color;
            mPenSettingView.setInfo(penInfo);
        }
    }
};
```

Using Pen Setting

■ Preventing Memory Leaks


- Call `SpenSettingPenLayout.close()` (in the `onDestroy()` method) to close your `SpenSettingPenLayout` instance when your application closes.

```
if (mPenSettingView != null) {  
    mPenSettingView.close();  
}
```

Using Eraser Setting

■ Project

- **Objective:** add a "Eraser setting" button to your application for setting preferences for the Eraser.
- **Description:** When the "Eraser setting" button is clicked, the `SpnSettingEraserLayout` View appears to allow the user to configure the settings for the Eraser. If the button is clicked again, the window closes.



- Reference: 4.1.3 section of `ProgrammingGuide_Pen.pdf`

Using S Pen

- References:
 - ProgrammingGuide_Pen.pdf

